

```

1: unit ResponseParser;
2:
3: //=====
4: //
5: //  ResponseParser.pas
6: //
7: //  Calls: AGCommand : AGResponseHandler
8: //          BCCCommand : BCResponseHandler
9: //          BUFCCommand : BUFCResponseHandler
10: //          BYCommand : BYResponseHandler
11: //          Main
12: //          PSCommand : PSResponseHandler
13: //          RXCommand : RXResponseHandler
14: //          SMCommand : SMResponseHandler
15: //          SQCommand : SQResponseHandler
16: //          TXCommand : TXResponseHandler
17: //          Variables
18: //
19: //  Called BY: Main : TfrmMain.SdpoSerial1RxData
20: //
21: //  Ver: 1.0.0
22: //
23: //  Date: 7 July 2013
24: //
25: //=====
26:
27:
28: {$mode objfpc}{$H+}
29:
30: interface
31:
32: uses
33:   Classes, Dialogs, SysUtils,
34:   //   Application Variables
35:   AppVariables, AGCommand, BCCCommand, BUFCCommand, BYCommand, PSCommand, RXCommand, SMCommand,
36:   SQCommand, TXCommand;
37:
38: procedure ParseResponse (vstrResponse : string);
39:
40: implementation
41:
42: //=====
43:
44: uses
45:   Main;
46:
47: procedure ParseResponse (vstrResponse : string);
48:
49: var
50:   vstrParameters : string;
51:   vintSpacePtr : Integer;
52:   vintTemp : Integer;
53:
54: begin
55:   if Length (vstrResponse) > 0 then
56:     begin
57:
58:
59:       //  MessageDlg('vstrResponse = ' + vstrResponse, mtInformation, [mbOk], 0 );

```

```

60:
61:     // First, we separate the Keyword and Parameters.
62:
63:     // The last character in the response will always be a <CR> terminator. The Keyword can
64:     // be 1, 2 or 3 characters long and is either followed by a <Sp>, or terminated by a
65:     // <CR>. Single character responses are error conditions and will always be followed by
66:     // a <CR>. 2 and 3 character responses may be followed by a <Sp> or terminated by a <CR>.
67:     // If followed by a <Sp> the response will always have one or more parameters following
68:     // the <Sp>. If terminated by a <CR>, there will be no parameters.
69:
70:     // Remove mysterious Null characters at the beginning of a PS response.
71:     if vstrResponse[1] = #0 then
72:         vstrResponse := Copy(vstrResponse,2, Length(vstrResponse));
73:
74:     // First we look for single character responses. They will always have a length of 2.
75:     if Length(vstrResponse) > 2 then
76:         begin
77:             // These must be two or three character responses, so now we look for a space to see
78:             // if there are any parameters
79:             vintSpacePtr := Pos (' ', vstrResponse);
80:             // If there is no space, there are no parameters
81:             if vintSpacePtr = 0 then
82:                 begin
83:                     gvstrKeywordRcvd := Copy(vstrResponse, 1, Length(vstrResponse)-1);
84:                     vstrParameters := '';
85:                 end
86:             else
87:                 begin
88:                     gvstrKeywordRcvd := Copy(vstrResponse, 1, vintSpacePtr-1);
89:                     vstrParameters := Copy(vstrResponse, vintSpacePtr+1, Length(vstrResponse)- (
vintSpacePtr+1));
90:                 end; //if vintSpacePtr = 0
91:             end
92:         else
93:             begin
94:                 // These must be one character responses
95:                 gvstrKeywordRcvd := vstrResponse[1];
96:                 vstrParameters := '';
97:             end; // if Length(vstrResponse) > 2
98:
99:             if (gvstrKeywordSent = gvstrKeywordRcvd) or (gvstrKeywordRcvd = '?') then
100:                 begin
101:                     gvblnKeywordMatched := True;
102:                     frmMain.tmrSendTimeout.Enabled := False;
103:                 end;
104:
105:                 Case gvstrKeywordRcvd of
106:                     'AG' : AGResponseHandler(gvstrKeywordRcvd, vstrParameters);
107:                     'BC' : BCResponseHandler(gvstrKeywordRcvd, vstrParameters);
108:                     'BUF' : BUFResponseHandler(gvstrKeywordRcvd, vstrParameters);
109:                     'BY' : BYResponseHandler(gvstrKeywordRcvd, vstrParameters);
110:                     'PS' : PSResponseHandler(gvstrKeywordRcvd, vstrParameters);
111:                     'RX' : RXResponseHandler(gvstrKeywordRcvd, vstrParameters);
112:                     'SM' : SMResponseHandler(gvstrKeywordRcvd, vstrParameters);
113:                     'SQ' : SQResponseHandler(gvstrKeywordRcvd, vstrParameters);
114:                     'TX' : TXResponseHandler(gvstrKeywordRcvd, vstrParameters);
115:                 Else
116:                     gvblnKeywordMatched := True;
117:                     frmMain.tmrSendTimeout.Enabled := False;

```

```
118:      End;//Case vstrKeyWord
119:
120:   end;
121:
122: end;// procedure ParseResponse (Response : string);
123:
124: end.//
125:
```